


Fuses

Under-hood Fuse/Relay Box



*: Not used

Fuse Number	Amps	Wire Color	Component (s) or Circuit (s) Protected
31	15 A	YEL/WHT	PGM-FI main relay
32	7.5 A	WHT/BLU	ECM, TCM, Clock, Stereo radio/cassette player, Maintenance reminder unit
33	20 A	BLK/RED	Radiator fan motor
34	—	—	Not used
35	20 A	WHT	Condenser fan motor, A/C compressor clutch
36	50 A	WHT/RED	No. 1 (30 A), No. 3 (7.5 A), No. 4 (20 A), No. 5 (20 A), No. 7 (20 A), No. 8 (20 A) fuses
37	40 A	BLU/WHT	Blower motor
38	30 A	BLK/GRN	Rear window defogger, Noise condenser
39	50 A	WHT/BLK	Ignition switch (BAT)
40	50 A	WHT	Combination light switch, No. 17 (10 A) fuse
41	100 A	—	Power distribution
42	20 A	WHT/GRN	Horn system, Brake system, Key interlock solenoid (A/T)
43	10 A	WHT/GRN	Turn signal/hazard relay
44	—	—	Not used
45	—	—	Not used
46	—	—	Not used