

Troubleshooting



Any abnormality must be corrected before continuing the test.
Because of the precise measurements needed, use a voltmeter and ammeter when testing.

Before performing any troubleshooting procedures check:

Fuses No. 15, 18, 38, 32, 31

Grounds No. 101, 201, 281

All electrical connections are clean and tight.

SYMPTOM	REMEDY
Compressor does not come on.	Perform the procedures in the flow chart. (page 22-6)
Low radiator fan (or condenser fan) does not run.	Perform the procedures in the flow chart. (page 22-9)
Compressor and radiator fan (or condenser fan) do not run.	Perform the procedures in the flow chart. (page 22-13)
	Discharge (high) pressure abnormally high or low.
Boost does not work.	See the fuel and emissions section.

Circuit Diagram

